

Master

9.4 or 10.4 metres

For arable and grassland



Standard equipment:

- Self-cleaning Prism roller® Ø45/50 cm **cast iron**
- Six pendular elements with **3D ground contouring**
- Drawbar with hitch cat. 3
- Transport wheels 15.0/55-17 10 PR
- Hydraulic folding
- Road lighting kit (LED)
- **Expert report required to obtain the general operatin licence for driving on public road**

Standard machine

Type	Working width	Transport width	Num. of sections	Support load	Axle load	Weight	Item no.	Price excl. VAT
Master 940 withoutbrake	9.30 m	3.00 m	6	1,670 kg	2,970 kg	4,845 kg	9701 0961	
Master 940 with brake	9.30 m	3.00 m	6	1,675 kg	2,970 kg	4,995 kg	9701 0975	
Master 1040 with brake	10.40 m	3.00 m	6	1,850 kg	3,180 kg	5,290 kg	5101 6033	

Options

Description	Note	Weight	Item no.	Price excl. VAT
Wheels 19,0/45-17 14 PR	surcharge on wheels 15.0/55-17 10 PR	120 kg	5102 1180	
NonStop-harrow for Master 940	3-rows, 12 mm tines, space between tines 62.5 mm air brakes necessary!	2,100 kg	5001 2000-1	
	harrow hydraulically height-adjustable	200 kg	5001 2630	
NonStop-harrow for Master 940	2-rows, with levelling bar, space between tines 75 mm air brakes necessary!	2,100 kg	5001 2500-1	
	harrow hydraulically height-adjustable	200 kg	5001 2630	
NonStop-harrow for Master 940	2-rows, with Ripperboard, space between tines 37.5 mm air brakes necessary!	2,200 kg	5001 2510-1	
	Ripperboard hydraulically tilt-adjustable	200 kg	5001 2520	
NonStop-harrow for Master 1040	3-rows, 12 mm tines, space between tines 62.5 mm	2,200 kg	5001 2100-1	
	harrow hydraulically height-adjustable	200 kg	5001 2630	
NonStop-harrow for Master 1040	2-rows, with levelling bar, space between tines 75 mm	2,200 kg	5001 2600-1	
	harrow hydraulically height-adjustable	200 kg	5001 2630	
NonStop-harrow for Master 1040	2-rows, with Ripperboard, space between tines 37.5 mm	2,300 kg	5001 2610-1	
	Ripperboard hydraulically tilt-adjustable	200 kg	5001 2620	
NonStop-attachment reinforced gauge wheels 195/55	surcharge on wheels 18x8.5	50 kg	50012760	
Hydraulic pressure compensation	incl. throttle screw, manometre, gas accumulator for a constant pressure distribution to the cantilvers		5102 1500	
Loose tines on drawbar	4 tines mounted at drawbar quick-change system for points with swept point	300 kg	5101 0051-1	
Loose tines on NonStop	1 tine 4 pieces recommended for NonStop	8 kg	9700 9594	
Adapter loose tines	If NonStop collides with tractor tyres	63 kg	9701 3742	

Additional information

Additional information	Note
NonStop-harrow	standard with straight tines (Item no. see above). optional with cranked tines (Item no. without -1), same price.
Final assembly roller on-site:	approx. 3 hours
Final assemb. NonStop-harrow on-site:	approx. 2 hours
Hydraulic connections required:	2x da (Master – folding and transport wheels) 1x da (for hydraulic tilt adjustment Ripperboard) 1x da (for hydraulic height adjustment harrow)

Front implements



NonStop-harrow 3-rows
Item no. 5001 2000-1 for Master 940
Item no. 5001 2100-1 for Master 1040



NonStop-harrow 2-rows
with levelling bar
Item no. 5001 2500-1 for Master 940
Item no. 5001 2600-1 for Master 1040



NonStop-harrow 2-rows with Ripperboard
Item no. 5001 2510-1 for Master 940
Item no. 5001 2610-1 for Master 1040
Option: hydraulic tilt adjustment for Ripperboard